# Coating thickness gauges SAUTER TF · TG



SAUTER TF

SAUTER TG

# Premium measuring devices for paint coating, lacquer coating etc.

## Features

- II LCD display, backlit, display of all information at a glance
- Offset-Accur: This function allows you to adjust the instrument precisely on the locally measured range by a two-point calibration. This results in a superior accuracy of approx. 1 % of the measured value
- Scan mode allows continuous measurement or single point measuring mode
- Mini Statistics Kit: displays the measured result, the average value and the max and the min value
- Internal memory up to 99 values
- Selectable measuring units: µm, mil
- · Base plate and calibration foils included
- Data interface RS-232 standard
- 2 Delivered in a hard carrying case

## SAUTER TG:

• External sensor for difficult-to-access measurements

# Technical data

- Precision:
- Standard: 3 % of measured value or  $\pm$  2,5  $\mu m$
- Offset-Accur: 1 % of measured value or  $\pm$  1  $\mu m$
- Minimal base thickness: 0,3 mm
- Dimensions WxDxH 65x35x126 mm
- Battery operation, batteries standard 2 x 1.5 V AAA
- Net weight approx. 81 g

## Accessories

- Software, interface cable included, SAUTER ATC-01
- Calibration foils for increased measuring accuracy (covers the range from 20 up to 2000  $\mu$ m, with < 3 % tolerance), SAUTER ATB-US07
- External sensor, Type FN, for TG, SAUTER ATG 01

STANDARD				OPTION
	FOCUS MEMORY	RS 232 STATISTIC	→ O ← I	 EARS SOFTWARE SOFTWARE

Model	Measuring range	Readout	Test object	Smallest sample surface	Option ISO Calibration		
	[Max]	[d]		(radius)		ISO	
SAUTER	μm	μm		mm		KERN	
TF 1250-0.1FN.	100   1250	0,1   1	Combination instrument: F/N	F: Convex: 1,5 Concave: 25		961-112	
TG 1250-0.1FN.	100   1250	0,1   1	Combination instrument: F/N	N: Convex: 3 Concave: 50		961-112	

# SAUTER Pictograms:



Adjusting program (CAL): For quick setting of the balance's accuracy. External adjusting weight required.



**Calibration block:** 

standard for adjusting or correcting the measuring device.




Peak hold function: capturing a peak value within a measuring process.

continuous capture and display



of measurements.

Scan mode:





PUSH/PULL

#### Length measurement: captures the geometric dimensions of

a test object or the movement during a test process.



# Focus function:

increases the measuring accuracy of a device within a defined measuring range.



Internal memory: to save measurements in the device memory.



Data interface RS-232 bidirectional, for connection of printer and PC.

4 USB

# Data interface USB: To connect the balance to a printer,

PC or other peripheral devices.



#### Data interface Infrared: To transfer data from the balance to a

printer, PC or other peripheral devices.



(optocoupler, digital I/O): SWITCH to connect relays, signal lamps, valves, etc.



#### Analogue interface: to connect a suitable peripheral device for analogue processing of the measurements.



using the saved values, the device STATISTIC calculates statistical data, such as average value, standard deviation etc.


a printer can be connected to the

GLP/ISO record keeping:

device to print out the measurements.

of measurements with date, time and

serial number. Only with SAUTER printers.








GLP PROTOCOL

S

UNIT

# Measuring units:





Measuring with tolerance range: Upper and lower limiting can be programmed individually, e.g. for sorting and dosing.



ZERO: Resets the display to "0".



# Battery operation:

Ready for battery operation. The battery type is specified for each device.



# Rechargeable battery pack:

rechargeable set.



### Mains adapter:

230V/50Hz in standard version for EU. On request GB, AUS or USA version available.



230 V

### Power supply:

Integrated, 230V/50Hz in EU. More standards e.g. GB, AUS or USA on request.



The mechanical movement is carried out by a motorised drive.



MOTOR

## Fast-Move:

the total length of travel can be covered by a single lever movement.

**ISO Calibration: ISO** The time required for ISO calibration +4 DAYS is shown in days in the pictogram.



\_\_\_

1 DAY

VARRANTY

### Package shipment:

The time required for internal shipping preparations is shown in days in the pictogram.

## Pallet shipment:

The time required for internal shipping preparations is shown in days in the pictogram.



The warranty period is shown in the pictogram.

Your SAUTER specialist dealer:



PROXIS Slovakia, spol. s r.o. Karloveská 63. 84101 Bratislava, SLOVAKIA

www.proxis-ndt.sk ndt@proxis.eu

